




Legend

-  Fixture Modification
-  Assembly Adder

FACTORY INSTALLATION

Intellect™ by LEVITON

Intellect Solo Sensor
 • Option V99(LV02)



Control




Driver





Manufacturing






Modules



Intellect Wireless Controller
 • Option V99(LV01)



Intellect Wireless In-Fixture Controller
 • Option V99(LV03)




EasySense by PHILIPS

Phillips EasySense Mount Sensor
 • Option V99(P02) - SNS200
 • Option V99(P03) - SNS300




Phillips EasySense for High Bay
 • Option V99(P04) - SNH200





CASAMBI

Casambi Bluetooth Controller
 • Option V99(C01) - CBU-ASR



Lutron Wireless Integration Guide

Legend  Fixture Modification
 Assembly Adder

Example Order Key
 LRTH2X2-LED840K032LUNV-B40(DS-1)V99(L06)
 Hi-lume 1% EcoSystem Driver & DFCSJ-OEM-OCC

FACTORY INSTALLATION

Lutron Vive Wireless Integral Fixture Controller


- Option V99(L05) - RF (DFCSJ-OEM-RF)
- Option V99(L06) - Daylight with Occupancy (DFCSJ-OEM-OCC)

Lutron Vive Wireless Integral Fixture Controller with EcoSystem

- Option V99(L05) - RF (DFCSJ-OEM-RF)
- Option V99(L06) - Daylight with Occupancy (DFCSJ-OEM-OCC)

Lutron T-Series 2-Channel Tunable White

- Option B40(T)



FACTORY OR IN-FIELD INSTALLATION*

Lutron Vive Wireless Individual Fixture Controller

- Option V99(L01) - 0-10V (FCJS-O10)

Lutron Vive Wireless Individual Fixture Controller with EcoSystem


- Option V99(L02) - EcoSystem (FCJS-ECO)

Lutron Vive Wireless Individual Fixture Controller

- Option V99(L03) - Occupancy (FC-SENSOR)
- Option V99(L04) - Vacancy (VSENSOR)


Lutron Vive Wireless Individual Fixture Controller with EcoSystem (FC-SENSOR or VSENSOR)

*These options can be purchased from others and installed in-field. Options ordered from factory will be factory installed wherever possible.




TUNABLE WHITE & STATIC WHITE DRIVERS


347V available, consult factory.




T-Series 2-Channel Tunable White 1% Option B40(T)



Hi-lume Premier EcoSystem 0.1% w/ Soft-on, Fade-to-Black Option B40(DS-0.1)





Hi-lume 1% EcoSystem w/ Soft-on, Fade-to-Black Option B40(DS-1)



5-Series 5% EcoSystem Option B40(5)

Legend

-  Fixture Modification
-  Assembly Adder

FACTORY INSTALLATION



Acuity nLight Dimming Device

- Option V99(A01) - n10-EZ-PH

Acuity nLight Dimming Device

- Option V99(A02) - n10-EZ-PH-EM



Enlighted Ruggedized Sensor

- Option V99(E03) - SU-5E-HRx-xx

Enlighted Micro Sensor

- Option V99(E04) - SU-5E-xx




Douglas Dialog Bluetooth Controller



- Option V99(D01) - BT-PP20-A

Douglas Dialog Bluetooth Fixture Controller

- Option V99(D02) - BT-FMS-A



Legend

-  Fixture Modification
-  Assembly Adder

FACTORY INSTALLATION



Luxon IOT Node
 • Option V99(N01) - IoT Node

Luxon Wireless Build-In Activator
 • Option V99(N02) - Wireless Build-In


Luxon Wireless Build-On Activator
 • Option V99(N03) - Wireless Build-On





Audacy 347V Luminaire Controller
 • Option V99(G01) - SCC-1000

Audacy Luminaire Controller (Internal)
 • Option V99(G02) - SCL-1000

Audacy Luminaire Controller (External)
 • Option V99(G03) - SCD-1000



Legend

-  Fixture Modification
-  Assembly Adder


FACTORY INSTALLATION

OSRAM

Connected Lighting Module (CLM)
 • Option V99(S01) - ZBHA-CLM-DIM

Connected Lighting Module (CLM)
 • Option V99(S02) - ZBHA-CLMDEXAL

SensiLUM™ Wireless Integrated Sensor
 • Option V99(S05) - SensiLUM



FACTORY OR IN-FIELD INSTALLATION

Wireless Control Module (WCM)
 • Option V99(S03) -EN-WCM-ZB

Wireless Area Lighting Controller (WALC)
 • Option V99(S04) -EN-WALC-ZB

